

KIWI HIGH SPEED ADAPTER KIT FOR KIWI SPINNING WHEELS

First remove the drive belt, brake band, flyer and whorl. Apply a drop of oil to the end of the flyer shaft and fit the new high speed whorl. Click the flyer into position and place the brake band over the bobbin.

Position the new shorter drive belt over the largest groove in the whorl and smallest groove in the wheel. This gives a flyer ratio of 7.5:1.

For finer yarns position the drive belt in the smallest groove in the whorl and largest groove in the wheel. This gives a flyer ratio of 15.5:1. The middle groove gives a ratio of 10:1.

When not using your Kiwi, release the tension on the drive belt by taking it off the flyer whorl.

Ashford Handicrafts Limited Factory and Showroom: 415 West Street PO Box 474, Ashburton 7700 New Zealand Telephone 64 3 308 9087 Facsimile 64 3 308 8664 Email: sales@ashford.co.nz Internet: www.ashford.co.nz



Ashford Handicrafts Limited Factory and Showroom: 415 West Street PO Box 474, Ashburton 7700 New Zealand Telephone 64 3 308 9087 Facsimile 64 3 308 8664 Email: sales@ashford.co.nz Internet: www.ashford.co.nz

KIWI HIGH SPEED ADAPTER KIT

FOR KIWI SPINNING WHEELS

KHSK

Batch # Packed

Ashford Guarantee

Thank you for purchasing this Ashford product. In the unlikely event there is any fault in manufacture we will replace the item. To validate our guarantee please visit our website, email or write to us.